


Xstamper® re-inking instructions

We strongly recommend using only Xstamper® Refill Ink to re-ink your Xstamper pre-inked rubber stamp. It has been specifically formulated to flow cleanly through the micropores of the Xstamper's laser-engraved rubber. Using ink other than Xstamper Refill Ink can clog these micropores and void the Xstamper warranty. Please follow the directions below for your respective Xstamper mount. After re-inking, please allow stamp to sit up to 24 hours to reach maximum saturation.



Remove the handle and place 2-4 drops of ink in the openings on either side of the spring as shown.




Slide the impression cartridge out of the handle. Place 2-3 drops of the same color ink in each of the 4 openings as shown.



Remove the handle and place 2-4 drops of the same color ink in the opening in the center of the mount.





Slide the impression cartridge out of the handle. Place 2-3 drops of the same color ink in the opening as shown.




Remove the white cap on top and place 2-4 drops of the same color ink in the opening in the center of the mount.



Slide the impression cartridge out of the handle. Place 2-3 drops of the same color ink in each of the openings as shown.



Firmly hold the teal handle and the white Impression Frame™ and pull apart. Use the corresponding color ink cartridge to put 2-3 drops of ink into the inking hole. Put 2-3 drops into each opening on the frame as well.



Put a few drops of the corresponding color ink in the XpeDater base and a few in the travel cap as needed.



Put a few drops of the corresponding color ink into the stamp base.

Xstamper® custom industrial stamps



item	description	color	price
22110	10ml bottle	lt. green	6.59
22111	10ml bottle	red	6.59
22112	10ml bottle	black	6.59
22113	10ml bottle	blue	6.59
22114	10ml bottle	green	6.59
22115	10ml bottle	purple	6.59
22116	10ml bottle	orange	6.59
22117	10ml bottle	yellow	6.59
22118	10ml bottle	pink	6.59
22119	10ml bottle	lt. blue	6.59
21111	10ml bottle	brown	6.59

item	description	color	price
22210	20ml bottle	lt. green	10.19
22211	20ml bottle	red	10.19
22212	20ml bottle	black	10.19
22213	20ml bottle	blue	10.19
22214	20ml bottle	green	10.19
22215	20ml bottle	purple	10.19
22216	20ml bottle	orange	10.19
22217	20ml bottle	yellow	10.19
22218	20ml bottle	pink	10.19
22611	60ml bottle	red	25.15
22612	60ml bottle	black	25.15
22613	60ml bottle	blue	25.15
22614	60ml bottle	green	25.15

item	description	color	price
22011	5 cartridge pack	red	6.59
22012	5 cartridge pack	black	6.59
22013	5 cartridge pack	blue	6.59



Xstamper® vX re-inking instructions



To re-ink Xstamper vX® message stamps, remove the handle and place 2-4 drops of the same color Xstamper® ink in the openings as shown. Allow ink to absorb overnight for best results.

To re-ink The Xstamper vX® date stamps remove the Base and place 2-4 drops of the same color Xstamper® ink in the cap pad, and 2-4 drops of the same color Xstamper ink in the hole as shown. Allow ink to absorb overnight for best results.